


5. Specified Data

1. ENGINE CONTROL MODULE (ECM) I/O SIGNAL



Content	Connector No.	Terminal No.	Signal (V)		Note	
			Ignition SW	Engine ON (Idling)		
			ON (Engine OFF)			
Crankshaft position sensor	Signal (+)	B84	8	0	±7	Sensor output waveform
	Signal (-)	B84	7	0	0	—
	Shield	B84	52	0	0	—
Camshaft position sensor	Signal (+)	B84	6	0	±7	Sensor output waveform
	Signal (-)	B84	5	0	0	—
	Shield	B84	52	0	0	—
Mass air flow sensor	Signal	B84	26	0 — 0.3	0.8 — 1.2	—
	Shield	B84	54	0	0	—
	GND	B84	25	0	0	—
Throttle position sensor	Signal	B84	24	Fully closed: 0.2 — 1.0 Fully opened: 4.2 — 4.7		—
	Power supply	B84	22	5	5	—
	GND	B84	25	0	0	—
Front oxygen sensor	Signal	B84	28	0	0 ↔ 0.9	—
	Shield	B84	56	0	0	—
Rear oxygen sensor	Signal	B84	27	0	0 ↔ 0.9	—
	Shield	B84	56	0	0	—
Engine coolant temperature sensor	B84	29	1.0 — 1.4	1.0 — 1.4	After warm-up	
Vehicle speed sensor 2	B84	57	0 or 5	0 or 5	"5" and "0" are repeatedly displayed when vehicle is driven.	

Content	Connector No.	Terminal No.	Signal (V)		Note
			Ignition SW	Engine ON (Idling)	
			ON (Engine OFF)		
Starter switch	B84	81	0	0	Cranking: 8 to 14
A/C switch	B84	80	ON: 10 – 13 OFF: 0	ON: 13 – 14 OFF: 0	—
Ignition switch	B84	79	10 – 13	13 – 14	—
Neutral position switch (MT)	B84	78	ON: 5.0±0.5 OFF: 0		● On MT model; switch is ON when gear is in neutral position.
Neutral position switch (AT)			ON: 0 OFF: 5.0±0.5		
Test mode connector	B84	75	5	5	When connected: 0

Content		Connector No.	Terminal No.	Signal (V)		Note
				Ignition SW		
				ON (Engine OFF)	Engine ON (Idling)	
Knock sensor	Signal	B84	30	2.8	2.8	—
	Shield	B84	56	0	0	—
AT/MT identification		B84	50	(AT) 5 (MT) 0	(AT) 5 (MT) 0	When measuring voltage between ECM and body.
Back-up power supply		B84	42	10 — 13	13 — 14	Ignition switch "OFF": 10 — 13
Control unit power supply		B84	15	10 — 13	13 — 14	—
			16			
Ignition control	# 1, # 2	B84	14	0	1 — 3.4	—
	# 3, # 4	B84	13	0	1 — 3.4	—
Fuel injector	# 1	B84	2	10 — 13	1 — 14	Waveform
	# 2	B84	1	10 — 13	1 — 14	Waveform
	# 3	B84	18	10 — 13	1 — 14	Waveform
	# 4	B84	17	10 — 13	1 — 14	Waveform
Idle air control solenoid valve	OPEN end	B84	12	—	1 — 13	Waveform
	CLOSE end	B84	11	—	13 — 1	Waveform
Fuel pump relay control		B84	84	ON: 0.5, or less OFF: 10 — 13	0.5, or less	—
A/C relay control		B84	85	ON: 0.5, or less OFF: 10 — 13	ON: 0.5, or less OFF: 13 — 14	—
Radiator fan relay 1 control		B84	77	ON: 0.5, or less OFF: 10 — 13	ON: 0.5, or less OFF: 13 — 14	—
			88			
Radiator fan relay 2 control		B84	61	ON: 0.5, or less OFF: 10 — 13	ON: 0.5, or less OFF: 13 — 14	With A/C vehicles only
Self-shutoff control		B84	86	10 — 13	13 — 14	—
Malfunction indicator lamp		B84	31	—	—	Light "ON": 1, or less Light "OFF": 10 — 14
Engine speed output		B84	33	—	0 — 13, or more	Waveform
Torque control signal		B84	49	5	5	—
Torque control cut signal		B84	36	8	8	—
Mass air flow signal for AT		B84	35	0 — 0.3	0.8 — 1.2	—
Purge control solenoid valve		B84	59	ON: 1, or less OFF: 10 — 13	ON: 1, or less OFF: 13 — 14	—
Atmospheric pressure sensor		B84	23	3.9 — 4.1	2.0 — 2.3	—
Pressure sources switching solenoid valve		B84	58	ON: 1, or less OFF: 10 — 13	ON: 1, or less OFF: 13 — 14	—
EGR solenoid valve		B84	60	ON: 1, or less OFF: 10 — 13	ON: 1, or less OFF: 13 — 14	—
Front oxygen sensor heater signal		B84	44	0 — 1.0	0 — 1.0	—
Rear oxygen sensor heater signal		B84	43	0 — 1.0	0 — 1.0	—
TCS signal		B84	34	0 — 7	0 — 7	Waveform
AT diagnosis input signal		B84	48	Less than 1 ↔ More than 4	Less than 1 ↔ More than 4	Waveform
GND (sensors)		B84	25	0	0	—

Content	Connector No.	Terminal No.	Signal (V)		Note
			Ignition SW	Engine ON (Idling)	
			ON (Engine OFF)		
GND (injectors)	B84	71	0	0	—
		72			
GND (ignition system)	B84	69	0	0	—
GND (power supply)	B84	95	0	0	—
		96			
GND (control systems)	B84	45	0	0	—
		46			
GND (oxygen sensor heater)	B84	70	0	0	—

2. ENGINE CONDITION DATA

Content	Specified data
Mass air flow	1.9 — 3.6 (g/sec): Idling
	7.0 — 14.8 (g/sec): 2,500 rpm racing
Engine load	1.9 — 3.6 (%): Idling
	7.0 — 14.8 (%): 2,500 rpm racing

Measuring condition:

- Engine is warmed up.
- Gear position is in “N” or “P” position.
- A/C is turned OFF.
- All accessory switches are turned OFF.